

Rotaflex Long Stroke Pumping Units components and Parts List

No.	Model	Part No.	Specifications
1	Rotaflex 900	2659170	Assembly, load belt, metric mod6.
2	Rotaflex 900	2561833	Assembly, wind guard load belt, metric.
3	Rotaflex 900	2612963	Assembly, reducer 350D w/bottom caliper/sprocket.
4	Rotaflex 900	1201601	Gauge, level STAUFF SNA 127 B/N/0/12 2EW.
5	Rotaflex 900	2611353	Seal, oil 415379, 3.750 ID x 4.756 OD x 0.5000 WD, nitrile.
6	Rotaflex 900	2524181	Gasket, 6 thk, cover, metric.
7	Rotaflex 900	2805919	Kit, brake pad, sintered type 5 hayes 610m 98-10860 brake, caliper kit 610m.
8	Rotaflex 900	2805921	kit ,brake pad sintered type 9 hayes m100 98-14180.
9	Rotaflex 900	2524985	Modifications, brake Caliper, Hayes mod5.
10	Rotaflex 900	2519566	Weldment, brake rotor disk, metric mod2.
11	Rotaflex 900	2426440	Bushing QD, F-3.625.
12	Rotaflex 900	2578363	Assembly, top drum metric mod6.
13	Rotaflex 900	222193	Chain, US-5021 mod1.
14	Rotaflex 900	199940	GREASE FITTING - 1/8 NPT.
15	Rotaflex 900	2576928	Valve, 3/8 NPT grease relief.
16	Rotaflex 900	2517392	Assembly, bottom sprocket drip tray, metric mod2.
17	Rotaflex 900	2452538	Assembly, boot mod5.
18	Rotaflex 900	2563024	Assembly, hand brake, metric mod5.
19	Rotaflex 900	2628314	Assembly, shaft top sprocket, metric.
20	Rotaflex 900	2628188	Sprocket, top US-5021, RF950.
21	Rotaflex 900	2614769	Assembly, weight box carriage, metric.
22	Rotaflex 900	2514446	Shaft, eccentric, carriage mod5.
23	Rotaflex 900	217013	Shim, 0.020, spare wheel.
24	Rotaflex 900	220921	Shim, 0.010, spare wheel.
25	Rotaflex 900	219323	Shim, 0.005, spare wheel.
26	Rotaflex 900	215196	Bearing component, nilos ring #663/653AV.
27	Rotaflex 900	196754	Bearing, tapered roller, cone 663.
28	Rotaflex 900	197347	Bearing, Tapered Roller, Cup 653.
29	Rotaflex 900	2514440	Wheel, carriage mod5.
30	Rotaflex 900	2620435	Spacer, round 3mm.
31	Rotaflex 900	196439	Bearing component, adapter nut AN-16.
32	Rotaflex 900	181739	Washer, lock internal tooth 0.750 STL Zn.
33	Rotaflex 900	205888	Bolt, hex 0.750-10 x 5.000 STL GR5.
34	Rotaflex 900	2514449	Shaft, straight, carriage mod5.
35	Rotaflex 900	406359	Zerk, grease 1/8IN NPT 90 DEG.
36	Rotaflex 900	448714	Zerk, grease 1/8IN NPT.
37	Rotaflex 900	196386	bearing, tapered roller, cup m231610.
38	Rotaflex 900	196821	bearing, tapered roller, cone m231649.
39	Rotaflex 900	214261	Bearing component, nilos ring #M231649/231610AV.

40	Rotaflex 900	2653695	Shaft, swivel mod6.
41	Rotaflex 900	2620463	Spacer, carriage wheel bearing, metric.
42	Rotaflex 900	196158	Bearing component, lock washer W-16.
43	Rotaflex 900	2649111	chain pin, mod6.
44	Rotaflex 900	2517212	Plate, 10 thk x 25.4 x 115.5 mm, feature.
45	Rotaflex 900	2352454	washer, .38, nord-lock carbon steel
46	Rotaflex 900	219780	Bolt, hex 0.375-16 x 1.000 STL GR8.
47	Rotaflex 900	2666799	Assembly, weight box LH orange wheel bracket, metric mod5.
48	Rotaflex 900	2666809	Assembly, weight box RH orange wheel bracket, metric mod5.
49	Rotaflex 900	196523	Assembly, wheel counterweight 900/1100.
50	Rotaflex 900	2682120	Spacer, short wheel bracket, metric mod2.
51	Rotaflex 900	2682122	Spacer, long wheel bracket, metric mod2.
52	Rotaflex 900	2667517	Machined, orange wheel bracket LH, metric.
53	Rotaflex 900	2517359	Plate, lock, weight box wheel bracket, metric mod2.
54	Rotaflex 900	181733	Washer, flat 0.375 SAE type A narrow STL GR5.
55	Rotaflex 900	195921	Washer, split lock 0.375 STL GR5 B18.21.1.
56	Rotaflex 900	195938	Bolt, hex 0.375-16 x 1.000 STL GR5.
57	Rotaflex 900	195889	Fastener, guide wheel bracket, counterweight assembly.
58	Rotaflex 900	194782	Nut, hex 0.750-10 STL GR5 Zn.
59	Rotaflex 900	195284	Screw, set SQ head 0.750-10 x 5.000 cup alloy STL GR5.
60	Rotaflex 900	266680	Assembly, weight box RH orange wheel bracket
61	Rotaflex 900	2667521	Machined, orange wheel bracket RH, metric.
62	Rotaflex 900	2656471	Assembly, wheel rollback, metric.
63	Rotaflex 900	2705094	Assembly, top sprocket door, metric mod6.
64	Rotaflex 900	2705096	Wldmt, top sprocket door, metric 2.5.
65	Rotaflex 900	182455	Pin, cotter 0.063 DIA 0.750 IN LG.
66	Rotaflex 900	2393762	Latch, center control, austin hardware ALH 105-50 ZN 1/4
67	Rotaflex 900	2393700	Handle, door 5655-25, modified.
68	Rotaflex 900	2517305	Weldment, top sprocket door latch, metric mod2.
69	Rotaflex 900	2690293	Doors, large counterweight drainback.
70	Rotaflex 900	2539716	Actuator, swing handle CR-19-56-15.
71	Rotaflex 900	2690296	Gasket, large door EMKA 1011-15.
72	Rotaflex 900	2539769	Rod, swing handle CR-64-1000-50 large cwt drainback, metric.
73	Rotaflex 900	2539766	Rod, end swing handle CR-51-15-24.
74	Rotaflex 900	2704118	Doors, small counterweight drainback.
75	Rotaflex 900	2481047	Unit, hydraulic, hawe, RF2.0.
76	Rotaflex 900	2710398	Pressure transducer.
77	Rotaflex 900	2710397	Pressure Gauge w/ 90 deg.
78	Rotaflex 900	2710006	Filter cartridge.
79	Rotaflex 900	3077060	Valve, check cartridge G0.250A 6963 0105-45.HW RK1-2.

80	Rotaflex 900	2710017	directional control valve.
81	Rotaflex 900	2710022	directional control valve.
82	Rotaflex 900	2711853	directional seated valve.
83	Rotaflex 900	2710396	Accumulator.
84	Rotaflex 900	2710010	Fluid level gauge with switch.
85	Rotaflex 900	2710014	Fluid level gauge.
86	Rotaflex 900	2710001	KAW power pack.
87	Rotaflex 900	2762361	Coil, Solenoid D06 24V.
88	Rotaflex 900	2665806	Adapter, hyd. 0.38 BSP male-0.38 BSP male, 3000psi, STL.
89	Rotaflex 900	2665813	Adapter, hyd. 0.75-16UNF O-ring male-0.38BSP male, 3000psi.
90	Rotaflex 900	2694687	Socket, 90deg BSP connection.
91	Rotaflex 900	2810925	Hose, hyd. rod side, rollback assembly mod2 layout.
92	Rotaflex 900	2810928	Hose, hyd. piston side, rollback assembly mod2 layou.
93	Rotaflex 900	958140	Cylinder, rollback 3x24 3000psi bailey#214-357.
94	Rotaflex 900	2665810	Hose, hydraulic, brake assembly mod2.
95	Rotaflex 900	2601927	Assembly, belt sensor left.
96	Rotaflex 900	2656182	Assembly, blet sensor right.
97	Rotaflex 900	2736648	Splitter, M12 to 2 X M8 Y connection.
98	Rotaflex 900	2733951	Assembly, top junction box with ACIC fitting.
99	Rotaflex 900	2632942	Sensor, top proximity, M30 X 1.5, threaded barrel.
100	Rotaflex 900	2644475	Sensor, vibration 4-20mA, 0-10g.
101	Rotaflex 900	2735701	Assembly, emergency stop-selector switch DW.
102	Rotaflex 900	2632945	Sensor, bottom proximity, IS.
103	Rotaflex 900	2735719	Assembly, barrier box, IS-DW.
104	Rotaflex 900	2736646	Cordset, left slot sensor to splitter, M8 .
105	Rotaflex 900	2632601	Cordset, single ended, splitter to top junction box.
106	Rotaflex 900	2632592	Cordset, single ended, top prox. to top junction box .
107	Rotaflex 900	2632593	Cordset, single ended, vibration sensor to top junction box.
108	Rotaflex 900	2735328	Cable, top junction to barrier box, ACIC mod3.
109	Rotaflex 900	2664521	Cordset, double ended, load cell cbl. to BB, IS mod3.
110	Rotaflex 900	2735899	Cordset, single ended, selector switch to bottom JB.
111	Rotaflex 900	2735898	Cordset, single ended, bottom prox. to bottom JB, IS.
112	Rotaflex 900	2664491	Cordset, double ended, load cell to tower, IS mod3.
113	Rotaflex 900	2735334	Cordset, bottom electrical enclosure to speed sentry M23.
114	Rotaflex 900	2598211	Assembly, top hood assisted, metric mod2.
115	Rotaflex 900	2655754	Spring, gas, Bansbach A4A4-45-480-1090-860N.
116	Rotaflex 900	195307	Caliper, top brake (contract description: modification, caliper(emergency brake).
117	Rotaflex 900	182380	Caliper, brake cast iron.
118	Rotaflex 900	206093	Brake, caliper kit 610M.

119	Rotaflex 900	829400	Assembly, L.A. brake rod 900, A.3 (design).
120	Rotaflex 900	220073	Kit, linear actuator 900.
121	Rotaflex 900	219184	Cover, actuator 900/1100.
122	Rotaflex 900	218374	BAR, flaT 0.375 X 1 X 4.547 IN LG feature.
123	Rotaflex 900	217000	PIN, chain mod1.
124	Rotaflex 900	215591	Wheel, carriage outside-machined.
125	Rotaflex 900	214567	Spacer, carriage wheel bearing.
126	Rotaflex 900	217013	Shim, 0.020, spare wheel.
127	Rotaflex 900	220921	Shim, 0.010, spare wheel.
128	Rotaflex 900	219323	Shim, 0.005, spare wheel.
129	Rotaflex 900	219780	Bolt, hex 0.375-16 X 1.000 STL GR8.
130	Rotaflex 900	196754	Bearing, tapered roller, cone 663 (metallic wheels) (contract description: bearing component, cone 663).
131	Rotaflex 900	197347	Bearing, tapered roller, cup 653 (metallic wheels) (contract description: bearing component, cup 653).
132	Rotaflex 900	196158	Bearing component, lock washer w-16.
133	Rotaflex 900	215196	Bearing component, nilos ring #663/653av.
134	Rotaflex 900	213872	Bearing component, nilos ring #593/592aav.
135	Rotaflex 900	196389	Plate, lock 0.38 THK 3.00 X 4.5 feature.
136	Rotaflex 900	181733	Washer, flat 0.375 SAE TYPE A narrow STL GR5.
137	Rotaflex 900	196523	Assembly, wheel counterweight 900/1100.
138	Rotaflex 900	195284	Set screw, 0.750-10UNC X 5.00 square head.
139	Rotaflex 900	195706	Spacer, 1.624 IN OD X 1.253 IN ID X 0.63 IN LG feature.
140	Rotaflex 900	213925	Fitting, grease-RELIEF 1/8 NPT, 0.25 to 1 psi relief press.
141	Rotaflex 900	213504	Bearing component, NILOS RING 46790/46720AV.
142	Rotaflex 900	195146	Bearing, tapered roller, cup 46720.
143	Rotaflex 900	197104	Bearing, tapered roller, cone 46790.
144	Rotaflex 900	181482	Adapter nut an-30.
145	Rotaflex 900	215837	Bearing component, lock washer w-30.
146	Rotaflex 900	213044	Shim, top sprocket nilos .188.
147	Rotaflex 900	214772	Assembly, wheel bracket LH 900/1100.
148	Rotaflex 900	210108	Assembly, wheel brkt RH 900/1100.
149	Rotaflex 900	219067	Assembly, Load belt 42 mod1 (contract description: load belt 42" assembly).
150	Rotaflex 900	226026	Sheet, CSM 0.13 X 4.50 X 59.00 LG
151	Rotaflex 900	212811	Cotter pin, T-head 900/1100 3/8 X2 LG.(TH-4).
152	Rotaflex 900	218959	Weldment, oil pickup tray.
153	Rotaflex 900	221199	Assembly, drip tray, bottom sprocket mod1.
154	Rotaflex 900	195370	Weldment, rotor disk, brake.
155	Rotaflex 900	196068	Bushing, QD F-3.
156	Rotaflex 900	202018	SWITCH, MURPHY, VS-2.
157	Rotaflex 900	2760032	Kit, top sprocket adjuster retrofit 2.0, mod1.
158	Rotaflex 900	195889	Fastener, guide wheel bracket, counterweight assembly.

159	Rotaflex 900	213619	Sensor, prox EFE II3015ANKG.
160	Rotaflex 900	380784	V-belt, 1/C162.
161	Rotaflex 900	196386	Bearing, tapered roller, cup m231610.
162	Rotaflex 900	196821	Bearing, tapered roller, cone m231649.
163	Rotaflex 900	202015	Bearing, tapered roller, cup 592a.
164	Rotaflex 900	214505	Bearing, tapered roller, cone 593.
165	Rotaflex 900	2589170	Adapter nut AN-17.
166	Rotaflex 900	214261	Bearing component, nilos ring #M231649/231610AV.
167	Rotaflex 900	214544	Bearing component, lock washer W-17.
168	Rotaflex 900	213914	shim, swivel shaft nilos .188.
169	Rotaflex 900	213921	Housing, carriage mod 1
170	Rotaflex 900	196439	Bearing component, adapter nut AN-16.
171	Rotaflex 900	222193	Chain US-5021 mod1.
172	Rotaflex 900	2690296	Gasket, large door EMKA 1011-1 5.
173	Rotaflex 900	181433	Bar, flat 0.750 x 4.75 x 55 in lg feature.
174	Rotaflex 900	191282	Seal, oil timken 415991V 3.500 ID 4.501 OD 0.438 WD vit (seal, HS CR 34892).
175	Rotaflex 900	2395977	SHAFT, CARRIAGE STRAIGHT 900
176	Rotaflex 900	2400536	Shaft, carriage eccentric 900.
177	Rotaflex 900	2805919	Kit, brake pad , sintered type 5 hayes 610m 98-10860 brake, caliper kit 610m
178	Rotaflex 900	222400	SHAFT,SWIVEL, MOD1
179	Rotaflex 900	2578363	Assembly, top drum metric mod6.
180	Rotaflex 900	222761	Conduit assembly, 900/1100.
181	Rotaflex 900	2605200	Assembly hood mod 1.
182	Rotaflex 900	260600	Pin, hood hinge mod 1.
183	Rotaflex 900	215121	Linch pin McMaster 90170A650.
184	Rotaflex 900	751022	Assembly, reducer 320d w/brake/sprocket.
185	Rotaflex 900	2526636	Assembly, reducer 320d w/brake/sprocket csa.
186	Rotaflex 900	2612012	Assembly, reducer 320d w/brake/sprocket mod1.
187	Rotaflex 1100	2843873	Assembly, load belt, metric.
188	Rotaflex 1100	2849899	Assembly, wind guard load belt, metric.
189	Rotaflex 1100	2562255	Assembly, reducer 500D w/bottom caliper/sprocket,.
190	Rotaflex 1100	1201601	Gauge, level stauff SNA 127 B/N/0/12 2EW.
191	Rotaflex 1100	2611353	Seal, oil 415379, 3.750 ID x 4.756 OD x 0.500 WD, nitrile.
192	Rotaflex 1100	2524181	Gasket, 6 thk, cover, metric.
193	Rotaflex 1100	2519566	Weldment, brake rotor disk, metric mod2.
194	Rotaflex 1100	2426440	Bushing QD, F-3.625.
195	Rotaflex 1100	2805919	Kit, brake pad , sintered type 5 hayes 610M 98-10860 brake, caliper kit 610M
196	Rotaflex 1100	2805921	Kit ,brake pad sintered type 9 hayes M100 98-14180.
197	Rotaflex 1100	2524985	Modifications, brake Caliper, Hayes mod5.
198	Rotaflex 1100	2837301	Assembly, top drum, metric.

199	Rotaflex 1100	448714	Zerk, grease 1/8IN NPT.
200	Rotaflex 1100	2576928	Valve, 3/8 NPT grease relief.
201	Rotaflex 1100	2301627	Chain, US-5042 mod5.
202	Rotaflex 1100	2517392	Assembly, bottom sprocket drip tray, metric mod2.
203	Rotaflex 1100	2452538	Assembly, boot mod5.
204	Rotaflex 1100	2563024	Assembly, hand brake, metric mod5.
205	Rotaflex 1100	2841625	Assembly, shaft top sprocket, metric.
206	Rotaflex 1100	196523	Assembly, wheel counterweight 900/1100.
207	Rotaflex 1100	218277	Shaft, swivel mod2.
208	Rotaflex 1100	214261	Bearing component, nilos ring #M231649/231610AV.
209	Rotaflex 1100	196821	Bearing, tapered roller, cone M231649.
210	Rotaflex 1100	196386	Bearing, Tapered roller, cup M231610.
211	Rotaflex 1100	2516063	Housing, carriage mod5.
212	Rotaflex 1100	197347	Bearing, tapered roller, cup 653.
213	Rotaflex 1100	196754	Bearing, tapered roller, cone 663.
214	Rotaflex 1100	215196	Bearing component, nilos ring #663/653AV.
215	Rotaflex 1100	2620463	Spacer, carriage wheel bearing, metric.
216	Rotaflex 1100	196158	Bearing component, lock washer W-16.
217	Rotaflex 1100	196439	Bearing component, adapter nut AN-16.
218	Rotaflex 1100	2514446	Shaft, eccentric, carriage mod5.
219	Rotaflex 1100	217013	Shim, 0.020, spare wheel.
220	Rotaflex 1100	220921	Shim, 0.010, spare wheel.
221	Rotaflex 1100	219323	Shim, 0.005, spare wheel.
222	Rotaflex 1100	2514440	Wheel, carriage mod5.
223	Rotaflex 1100	2620435	Spacer, round 3mm.
224	Rotaflex 1100	181739	Washer, lock internal tooth 0.750 STL Zn.
225	Rotaflex 1100	205888	Bolt, hex 0.750-10 x 5.000 STL GR5.
226	Rotaflex 1100	2514449	Shaft, straight, carriage mod5.
227	Rotaflex 1100	221024	Chain pin, RF1100 series.
228	Rotaflex 1100	2517212	Plate, 10 thk x 25.4 x 115.5 mm, feature.
229	Rotaflex 1100	2352454	Washer, .38, nord-lock carbon steel.
230	Rotaflex 1100	219780	Bolt, hex 0.375-16 x 1.000 STL GR8.
231	Rotaflex 1100	406359	Zerk, grease 1/8IN NPT 90 DEG.
232	Rotaflex 1100	448714	Zerk, grease 1/8IN NPT.
233	Rotaflex 1100	182455	Pin, cotter 0.063 DIA 0.750 IN LG.
234	Rotaflex 1100	2393700	Handle, door 5655-25, modified.
235	Rotaflex 1100	2517305	Weldment, top sprocket door latch, metric mod2.
236	Rotaflex 1100	2393762	Latch, center control, Austin hardware ALH 105-50 ZN 1/.
237	Rotaflex 1100	2539716	Actuator, swing handle CR-19-56-15.
238	Rotaflex 1100	2539769	Rod, swing handle CR-64-1000-50 large cwt drainback, metric.
239	Rotaflex 1100	2539766	Rod, end swing handle CR-51-15-24.
240	Rotaflex 1100	2704118	Doors, small counterweight drainback.

241	Rotaflex 1100	2690296	Gasket, large door EMKA 1011-15
242	Rotaflex 1100	2481047	Unit, hydraulic, hawe, RF2.0.
243	Rotaflex 1100	2710398	Pressure transducer.
244	Rotaflex 1100	2710397	Pressure gauge w/ 90 deg.
245	Rotaflex 1100	2710006	Filter cartridge.
246	Rotaflex 1100	3077060	Valve, check cartridge G0.250A 6963 0105-45.HW RK1-2.
247	Rotaflex 1100	2710017	Directional control valve.
248	Rotaflex 1100	2710022	Directional control valve.
249	Rotaflex 1100	2711853	Directional seated valve.
250	Rotaflex 1100	2710396	Accumulator.
251	Rotaflex 1100	2710010	Fluid level gauge with switch
252	Rotaflex 1100	2710014	Fluid level gauge.
253	Rotaflex 1100	2710001	KAW power pack.
254	Rotaflex 1100	2762361	Coil, Solenoid D06 24V.
255	Rotaflex 1100	958140	Cylinder, rollback 3x24 3000psi bailey#214-357.
256	Rotaflex 1100	2665806	Adapter, hyd. 0.38 BSP male-0.38 BSP male, 3000psi, STL.
257	Rotaflex 1100	2665813	Adapter, hyd. 0.75-16UNF O-ring male-0.38BSP male, 3000psi.
258	Rotaflex 1100	2694687	Socket, 90deg BSP connection.
259	Rotaflex 1100	2810925	Hose, hyd. rod side, rollback assembly mod2 layout.
260	Rotaflex 1100	2810928	Hose, hyd. piston side, rollback assembly mod2 layout.
261	Rotaflex 1100	2665810	Hose, hydraulic, brake assembly mod2.
262	Rotaflex 1100	2601927	Assembly, belt sensor left.
263	Rotaflex 1100	2656182	Assembly, belt sensor right.
264	Rotaflex 1100	2736648	Splitter, M12 to 2 X M8 Y connection 1.
265	Rotaflex 1100	2733951	Assembly, top junction box with ACIC fitting 1.
266	Rotaflex 1100	2632942	Sensor, top proximity, M30 X 1.5, threaded barrel 1.
267	Rotaflex 1100	2644475	Sensor, vibration 4-20mA, 0-10g 1.
268	Rotaflex 1100	2735701	Assembly, emergency stop-selector switch DW.
269	Rotaflex 1100	2632945	Sensor, bottom proximity, IS.
270	Rotaflex 1100	2735719	Assembly, barrier box, IS-DW.
271	Rotaflex 1100	2736646	Cordset, left slot sensor to splitter, M8 .
272	Rotaflex 1100	2632601	Cordset, single ended, splitter to top junction box .
273	Rotaflex 1100	2632592	Cordset, single ended, top prox. to top junction box.
274	Rotaflex 1100	2632593	Cordset, single ended, vibration sensor to top junction box.
275	Rotaflex 1100	2735328	Cable, top junction to barrier box, ACIC mod3.
276	Rotaflex 1100	2664521	Cordset, double ended, load cell cbl. to BB, IS mod3.
277	Rotaflex 1100	2735899	Cordset, single ended, selector switch to bottom JB.
278	Rotaflex 1100	2735898	Cordset, single ended, bottom prox. to bottom JB, IS.
279	Rotaflex 1100	2664491	Cordset, double ended, load cell to tower, IS mod3.
280	Rotaflex 1100	2735334	Cordset, bottom electrical enclosure to speed sentry M23.

281	Rotaflex 900, 100 hp VSD	1608357	Transformer, 1500 va with fuse.
282	Rotaflex 900, 100 hp VSD	1608509	Fuse, class cc 9a 600v time delay.
283	Rotaflex 900, 100 hp VSD	717758	Fuse, atdr15 600v.
284	Rotaflex 900, 100 hp VSD	755356	VSD panel fan 6 inch, 110v ac
285	Rotaflex 900, 100 hp VSD	1735391	FUSE, 6.3A 5X20 MM SLO BLO for speed sentry power.
286	Rotaflex 900, 100 hp VSD	2458891	Fan, Exhaust with filter, 120V, IP55, PF43000.
287	Rotaflex 900, 100 hp VSD	1329205	Wellpilot Rpoc display keypad.
288	Rotaflex 900, 100 hp VSD	2002802	Pc assymbly,EGD,w/led backlight.
289	Rotaflex 900, 100 hp VSD	1980048	Breaker, circuit 200a 600v, 3 pole.
290	Rotaflex 900, 100 hp VSD	1980754	Fan 4715SL-05W-B60-UR6 DC24V 1.20A ROHS.
291	Rotaflex 900, 100 hp VSD	2518997	PCB GD,4075,M,500-040-520.
292	Rotaflex 900, 100 hp VSD	2518999	PCB GD,4075,M,500-073-650.
293	Rotaflex 900, 100 hp VSD	2519000	PCB PS, A1000, FAN_MC, 400V, M 500-048-5.
294	Rotaflex 900, 100 hp VSD	2369030	PCB TB,YAI,M,100-224-686.
295	Rotaflex 900, 100 hp VSD	2518996	PCB CONTROL A1000 2/4/600V 500-223-970 M.
296	Rotaflex 900, 100 hp VSD	1606773	Drive reactor for RF950 and RF900 SIL2 100HP VSD.
297	Rotaflex 900, 100 hp VSD	1849078	Amplifier, YASKAWA A1000, 165A.
298	Rotaflex 900, 100 hp VSD	1986863	Transistor module, 480V, BM4-150.
299	Rotaflex 900, 100 hp VSD	2585584	Kit, braking resistor and installation kit, 2X6AWG, 16kW Res.
300	Rotaflex 900, 100 hp VSD	1773491	PC assembly ,CPU II,WELL PILOT RPOC.
301	Rotaflex 900, 100 hp VSD	1131921	Safety Barrier for Load Cell connection to wellpilot RPOC.
302	Rotaflex 900, 100 hp VSD	1131924	Barrier, safety, 1K OHM, 7764.
303	Rotaflex 900, 100 hp VSD	1731604	Relay, DPDT 12V 250VAC/6A din rail mountable.
304	Rotaflex 900, 100 hp VSD	2308070	power supply, mini line 2 12V 4.5A single phase input.
305	Rotaflex 900, 100 hp VSD	1946843	Relay, SPDT 24V 250VAC/6A din rail mountable.
306	Rotaflex 900, 100 hp VSD	2026825	PC assembly, load cell protection board.

307	Rotaflex 900, 100 hp VSD	1847649	Kit, RPOC, EXP IO, Install for wellpilot RPOC.
308	Rotaflex 900, 100 hp VSD	1900026	RS-485 isolator board for wellpilot RPOC.
309	Rotaflex 900, 100 hp VSD	2583253	PRV power supply, 24v 150w phoenix contact.
310	Rotaflex 900, 100 hp VSD	1946850	24V DPDT relay.
311	Rotaflex 900, 100 hp VSD	1285008	Relay, SPDT 12V 250VAC/6A din rail mountable.
312	Rotaflex 900, 100 hp VSD	1731599	Fuse, 2A for DC supply.
313	Rotaflex 900, 100 hp VSD	896577	Fuse, 1 AMP for DC supply.
314	Rotaflex 900, 100 hp VSD	2914823	Harmonic Filter, 100HP, revcon.
315	Rotaflex 900, 100 hp VSD	2036401	MCCB 200A TP,36kA.
316	Rotaflex 900, 100 hp VSD	2031381	Fuse HRC 10A, SIZE(10X38), 500V,CLASS gG, 120KA.
317	Rotaflex 900, 100 hp VSD	2031019	Fuse HRC 2A, SIZE(10X38), 500V,CLASS gG.
318	Rotaflex 900, 100 hp VSD	2031381	Fuse LINK 4A SIZE-10x38 gG 120kA 500V.
319	Rotaflex 900, 100 hp VSD	2031325	Fuse HRC 6A, SIZE(10X38), 500V,CLASS gG, 120KA.
320	Rotaflex 900, 100 hp VSD	2031568	High speed fuse link 200A.
321	Rotaflex 900, 100 hp VSD	2046858	Transformer 1.5 KVA, 415/110V, 13.6 A.
322	Rotaflex 900, 100 hp VSD	2046710	Transformer 2.5 KVA, 415/110V, 22.7 A.
323	Rotaflex 900, 100 hp VSD	2001310	Exhaust fan 12" 322mm X 322mm 115V AC, IP55 RAL 7035.
324	Rotaflex 900, 100 hp VSD	3130545	Thermostat for heater normally closed.
325	Rotaflex 900, 100 hp VSD	3130546	Thermostat for fan normally open.
326	Rotaflex 900, 100 hp VSD	2038054	PTC heater 50w 120-240vac.
327	Rotaflex 900, 100 hp VSD	2029061	Extended rotary handle NSX100/160/250.
328	Rotaflex 900, 100 hp VSD	2031321	32A control fuse base size(10x38).
329	Rotaflex 900, 100 hp VSD	2044145	Selector switch 3 position 22mm dia plastic bezel.
330	Rotaflex 900, 100 hp VSD	2040745	Potentiometer 2k 22mm dia black line.
331	Rotaflex 900, 100 hp VSD	2001307	Louver 12" SIZE 322mm IP55 RAL7035.
332	Rotaflex 900, 100 hp VSD	2033237	Indication lamp red 12V DC 22.5mm Dia – LED.

333	Rotaflex 900, 100 hp VSD	1980754	FAN 4715SL-05W-B60-UR6 DC24V 1.20A ROHS.
334	Rotaflex 900, 100 hp VSD	2518997	PCB GD,4075,M,500-040-520.
335	Rotaflex 900, 100 hp VSD	2518999	PCB GD,4075,M,500-073-650.
336	Rotaflex 900, 100 hp VSD	2519000	PCB PS, A1000, FAN_MC, 400V, M 500-048-5.
337	Rotaflex 900, 100 hp VSD	2369030	PCB TB,YAI,M,100-224-686.
338	Rotaflex 900, 100 hp VSD	2518996	PCB control A1000 2/4/600V 500-223-970 M.
339	Rotaflex 900, 100 hp VSD	1606773	Drive reactor for RF950 and RF900 SIL2 100HP VSD.
340	Rotaflex 900, 100 hp VSD	1849078	Amplifier, YASKAWA A1000, 165A.
341	Rotaflex 900, 100 hp VSD	1986863	Transistor module, 480V, BM4-150.
342	Rotaflex 900, 100 hp VSD	2585584	Kit, braking resistor and installation Kit, 2X6AWG, 16kW Res.
343	Rotaflex 900, 100 hp VSD	1773491	PC assembly, CPU II,well pilot RPOC.
344	Rotaflex 900, 100 hp VSD	2732252	HMI, EX707, EXOR 7 IN. TFT 16. 9 LED - 16M.
345	Rotaflex 900, 100 hp VSD	1131921	Safety barrier for load cell connection to wellpilot RPOC.
346	Rotaflex 900, 100 hp VSD	1131924	Barrier, safety, 1K OHM, 7764.
347	Rotaflex 900, 100 hp VSD	1731604	Relay, DPDT 12V 250VAC/6A din rail mountable.
348	Rotaflex 900, 100 hp VSD	2308070	Power supply, mini Line 2 12V 4.5A single phase input.
349	Rotaflex 900, 100 hp VSD	2740561	Cable, display EXOR EX707 TO RPOC J6 connector 36 in.
350	Rotaflex 900, 100 hp VSD	1946843	Relay, SPDT 24V 250VAC/6A din rail mountable.
351	Rotaflex 900, 100 hp VSD	2026825	PC assembly, load cell protection board.
352	Rotaflex 900, 100 hp VSD	1847649	Kit, RPOC, EXP IO, install for wellpilot RPOC.
353	Rotaflex 900, 100 hp VSD	1900026	RS-485 ISOLATOR board for wellpilot RPOC.
354	Rotaflex 900, 100 hp VSD	2583253	PRV power supply, 24V 150W phoenix contact.
355	Rotaflex 900, 100 hp VSD	1946850	24V DPDT relay .
356	Rotaflex 900, 100 hp VSD	1285008	Relay, SPDT 12V 250VAC/6A din rail mountable.
357	Rotaflex 900, 100 hp VSD	1731599	Fuse, 2A for DC supply.
358	Rotaflex 900, 100 hp VSD	896577	Fuse, 1 AMP for DC supply.

359	Rotaflex 900, 100 hp VSD	2036401	200A TP MCCB,36KA,WITH O/C & S/C release TM-200D (NSX 250F).
360	Rotaflex 900, 100 hp VSD	2031331	Fuse HRC 20A, size(10x38), 500v,class gG, 120KA.
361	Rotaflex 900, 100 hp VSD	2031381	Fuse HRC 10A, size(10x38), 500v,class gG, 120KA.
362	Rotaflex 900, 100 hp VSD	2031019	Fuse HRC 2A, size(10X38), 500V,CLASS gG.
363	Rotaflex 900, 100 hp VSD	2031381	Fuse link 4a size-10x38 gG 120kA 500V.
364	Rotaflex 900, 100 hp VSD	2031325	F Fuse HRC 6A, size(10X38), 500V,CLASS gG, 120KA.
365	Rotaflex 900, 100 hp VSD	2001310	Exhaust fan, 12" 322MM x 322MM, 230V AC, IP55, RAL 7035.
366	Rotaflex 900, 100 hp VSD	3130545	Thermostat for heater normally closed.
367	Rotaflex 900, 100 hp VSD	3130546	Thermostat for fan normally open.
368	Rotaflex 900, 100 hp VSD	2038054	PTC heater 50w 120-240vac.
369	Rotaflex 900, 100 hp VSD	2950998	100HP VSD 415V, 173A, ATV930D90N4, SIL3.
370	Rotaflex 900, 100 hp VSD	2046710	Transformer 2.5 KVA, 415/110V.
371	Rotaflex 900, 100 hp VSD	3052927	Control block atv900 - 200v to 690v / all power rating.
372	Rotaflex 900, 100 hp VSD	3052928	Fortis control block terminals - for ATV900 control block.
373	Rotaflex 900, 100 hp VSD	VX4PPD90N 4	Power board - 400V / SC-S5 / 90kW.
374	Rotaflex 900, 100 hp VSD	VX5VPS500 1	Fan kit - 200V-400V / SC-S5 / DC24V D172x50.8mm.
375	Rotaflex 900, 100 hp VSD	2001307	Louver 12" size 322mm IP55 RAL7035.
376	Rotaflex 900, 100 hp VSD	2044145	Selector switch 3 position 22mm dia plastic bezel.
377	Rotaflex 900, 100 hp VSD	2040745	Potentiometer 2k 22mm dia black line.
378	Rotaflex 900, 100 hp VSD	2033237	INDICATION LAMP RED 12V DC 22.5mm Dia – LED.
379	Rotaflex 900, 100 hp VSD	2029061	Extended rotary handle NSX100/160/250.
380	Rotaflex 900, 100 hp VSD	2914823	Harmonic filter, 100hp, revcon.
381	Rotaflex 900, 100 hp VSD	2035116	Circuit breaker, 25a.
382	Rotaflex 900, 100 hp VSD	2035009	Circuit breaker, 10a.
383	Rotaflex 900, 100 hp VSD	1773491	PC assembly ,CPU II,well pilot RPOC.

384	Rotaflex 900, 100 hp VSD	2732252	HMI, EX707, EXOR 7 IN. TFT 16. 9 LED - 16M.
385	Rotaflex 900, 100 hp VSD	1131921	Safety barrier for load cell connection to wellpilot RPOC.
386	Rotaflex 900, 100 hp VSD	1131924	Barrier, safety, 1K OHM, 7764.
387	Rotaflex 900, 100 hp VSD	1731604	Relay, DPDT 12V 250VAC/6A din rail mountable.
388	Rotaflex 900, 100 hp VSD	2308070	Power supply, mini line 2 12v 4.5a single phase input.
389	Rotaflex 900, 100 hp VSD	2740561	Cable, display EXOR EX707 TO RPOC J6 connector 36 in.
390	Rotaflex 900, 100 hp VSD	1946843	Relay, SPDT 24V 250VAC/6A din rail mountable.
391	Rotaflex 900, 100 hp VSD	2026825	PC assembly, load cell protection board.
392	Rotaflex 900, 100 hp VSD	1847649	Kit, RPOC, EXP IO, install for wellpilot RPOC.
393	Rotaflex 900, 100 hp VSD	1900026	RS-485 ISOLATOR board for wellpilot RPOC.
394	Rotaflex 900, 100 hp VSD	2583253	PRV power supply, 24V 150W phoenix contact.
395	Rotaflex 900, 100 hp VSD	1946850	24V DPDT relay .
396	Rotaflex 900, 100 hp VSD	1285008	Relay, SPDT 12V 250VAC/6A din rail mountable.
397	Rotaflex 900, 100 hp VSD	1731599	Fuse, 2A for DC supply.
398	Rotaflex 900, 100 hp VSD	896577	Fuse, 1 AMP for DC supply.
399	Rotaflex 900, 100 hp VSD	2585584	Kit, braking resistor and installation Kit, 2X6AWG, 16kW Res.
400	Rotaflex 1100, 200 hp VSD	2585586	Kit, braking resistor and installation Kit, 2X6AWG, 25kW Res.
401	Rotaflex 1100, 200 hp VSD	2965564	Harmonic filter, 250hp, revcon.
402	Rotaflex 1100, 200 hp VSD	2036641	MCCB 500A TP,50kA, 250HP VSD, Schneider electric.
403	Rotaflex 1100, 200 hp VSD	2031019	Fuse HRC 2A, SIZE(10X38), 500V,class Gg.
404	Rotaflex 1100, 200 hp VSD	2031325	Fuse HRC 6A, SIZE(10X38), 500V, class gG, 120KA.
405	Rotaflex 1100, 200 hp VSD	2031331	Fuse HRC 20A, SIZE(10X38), 500V, class gG, 120KA.
406	Rotaflex 1100, 200 hp VSD	2031381	Fuse HRC 10A, SIZE(10X38), 500V, class gG, 120KA.
407	Rotaflex 1100, 200 hp VSD	2001310	Exhaust fan, 12" 322MM x 322MM, 230V AC, IP55, RAL 7035.
408	Rotaflex 1100, 200 hp VSD	3130545	Thermostat for heater normally closed.
409	Rotaflex 1100, 200 hp VSD	3130546	Thermostat for fan normally open.

410	Rotaflex 1100, 200 hp VSD	2038054	PTC heater 50W 120-240VAC.
411	Rotaflex 1100, 200 hp VSD	2997911	Drive module, 200HP, ATV930C16N4, Schneider Electric.
412	Rotaflex 1100, 200 hp VSD	2046710	Transformer 2.5 KVA, 415/110V.
413	Rotaflex 1100, 200 hp VSD	3052927	Control block ATV900 - 200V to 690V / all power rating.
414	Rotaflex 1100, 200 hp VSD	3052928	Fortis control block terminals - for ATV900 control block.
415	Rotaflex 1100, 200 hp VSD	3052930	For VSD - 400V / S7 / 220kW.
416	Rotaflex 1100, 200 hp VSD	3052931	Fan control board - 400V / S7.
417	Rotaflex 1100, 200 hp VSD	3052933	Fan powerelectronic - size 11/12/13/14/15.
418	Rotaflex 1100, 200 hp VSD	3052934	Fan controlelectronic - 24dc size 11/12/13.
419	Rotaflex 1100, 200 hp VSD	2029060	Mccb rotary handle for breaker.
420	Rotaflex 1100, 200 hp VSD	2044145	SELECTOR SWITCH 3 POSITION 22mm DIA PLASTIC BEZEL
421	Rotaflex 1100, 200 hp VSD	2040745	Potentiometer 10k 22mm dia black line.
422	Rotaflex 1100, 200 hp VSD	2033237	Indication lamp red 12V DC 22.5mm Dia – LED.
423	Rotaflex 1100, 200 hp VSD	2001307	LOUVER 12" SIZE 322mm IP55 RAL7035
424	Rotaflex 1100, 200 hp VSD	2031381	fuse link 4A size-10x38 gG 120kA 500V.
425	Rotaflex 1100, 200 hp VSD	2035116	Circuit breaker, 25A.
426	Rotaflex 1100, 200 hp VSD	2035009	Circuit breaker, 10A
427	Rotaflex 1100, 200 hp VSD	1773491	PC assembly, CPU II,well pilot RPOC.
428	Rotaflex 1100, 200 hp VSD	2732252	HMI, EX707, EXOR 7 IN. TFT 16. 9 LED - 16M.
429	Rotaflex 1100, 200 hp VSD	1131921	Safety barrier for load cell connection to wellpilot RPOC.
430	Rotaflex 1100, 200 hp VSD	1131924	Barrier, safety, 1K OHM, 7764.
431	Rotaflex 1100, 200 hp VSD	1731604	Relay, DPDT 12V 250VAC/6A din rail mountable.
432	Rotaflex 1100, 200 hp VSD	2308070	Power supply, mini line 2 12V 4.5A single phase input.
433	Rotaflex 1100, 200 hp VSD	2740561	Cable, display EXOR EX707 TO RPOC J6 connector 36 in.
434	Rotaflex 1100, 200 hp VSD	1946843	Relay, SPDT 24V 250VAC/6A din rail mountable.
435	Rotaflex 1100, 200 hp VSD	2026825	PC assembly, load cell protection board.

436	Rotaflex 1100, 200 hp VSD	1847649	Kit, RPOC, EXP IO, install for wellpilot RPOC.
437	Rotaflex 1100, 200 hp VSD	1900026	RS-485 ISOLATOR board for wellpilot RPOC.
438	Rotaflex 1100, 200 hp VSD	2583253	PRV power supply, 24V 150W phoenix contact.
439	Rotaflex 1100, 200 hp VSD	1946850	24V DPDT relay.
440	Rotaflex 1100, 200 hp VSD	1285008	Relay, SPDT 12V 250VAC/6A din rail mountable.
441	Rotaflex 1100, 200 hp VSD	1731599	Fuse, 2A for DC supply.
442	Rotaflex 1100, 200 hp VSD	896577	Fuse, 1 AMP for DC supply.